

BEAD BREAKER & PUMP CHART

BEAD BREAKER APPLICATION GUIDE

											
			10508	10876	10590	10500	10502	10592	10877	10875	10504
●		10101	NA	NA	10201	10200	NA	10202	10839	10825	NA
●		10895	NA	NA	NA	10230	NA	10237	10821	10820	NA
●		10102	NA	NA	NA	10221	NA	10233	10841	10826	NA
●		10107	NA	NA	NA	10228	NA	10220	10847	10832	NA
●		10109	NA	NA	NA	10229	NA	10223	10848	10837	NA
●		10105	10213*	NA	10206	10205	NA	10222	10844	10829	NA
●		10100	10204*	NA	10208	10207	NA	10209	10838	10824	NA
●		10896	NA	NA	NA	10231	NA	10238	10823	10822	NA
●		10104	10224*	NA	NA	10212	NA	10235	10843	10828	NA
●		10103	NA	NA	NA	10227	NA	10234	10842	10827	10211
●		40600	NA	NA	NA	40610	NA	40613	40619	40616	NA
●		40601	NA	NA	NA	40611	NA	40614	40620	40617	NA
●		40602	NA	NA	NA	40612	NA	40615	40621	40618	NA
●		10106	NA	NA	NA	10203	NA	10236	10845	10830	NA

*10601K NOT INCLUDED

BEAD BREAKER APPLICATION GUIDE

- - SINGLE PIECE RIM
- - 2 PIECE RIM
- - 3 PIECE RIM
- - 5 PIECE RIM
- - ALL WHEEL ASSEMBLIES



BEAD BREAKER KITS COME WITH:

- 10604 - 8 ft. Hose assembly (10610) with Hose Coupler (10605)
- 10601K - Air Reducer & 6" Whip Hose

BEAD BREAKER & PUMP APPLICATION CHART IS BASED ON CONFIGURATION NOT BY RECOMMENDED USAGE. PLEASE CONSULT WITH AN ESCO SALES REPRESENTATIVE FOR MORE INFORMATION ABOUT APPLICATION & KIT CONFIGURATIONS.